

ZXR-40A Transformer Winding Resistance Tester



CONTENT

1. GENERAL.....	2
2. PERFORMANCE INDEX.....	3
3. PANEL DESCRIPTION.....	3
4. TESTING AND OPERATING METHOD.....	4
5. PRECAUTIONS.....	10
6. TROUBLESHOOTING.....	10
7. TRANSPORTATION AND STORAGE.....	10
8. UNPACKING AND INSPECTION.....	11
9. OTHERS.....	11

Thank you very much for selecting our products!



For your better use of this instrument, you are kindly requested to read this manual carefully before you use it, so as to understand its major performances and operation method.



- Caution:**
- ① It is not allowed to remove the wiring and directly switch off the power supply during the measurement.
 - ② For the no-load voltage regulating transformer, it is not allowed to switch the tapping switch during the measurement.
 - ③ In case of a sudden power failure during the measurement, this instrument can discharge automatically. Please do not remove the wiring immediately. Wait for at least 30 seconds before the connection can be removed.
 - ④ The three-phase measurement applies to the windings of YN connection. For the windings of yn connection, since difference exists between the three-phase and single-phase measurement results due to the effect of the resistance of the copper bus connected, the single-phase measurement is recommended.
 - ⑤ Caution: The three-phase measurement result does not include the resistance value of the neutral lead. Therefore, it is suggested to at least verify one data using the single-phase testing method for each phase after completing the measurement of three-phase resistance value, so as to determine if the neutral lead is normal.

1. General

This fast DC resistance tester (hereinafter referred to as DC resistance tester) is the product of the latest generation for measuring the DC resistance of transformer and is optimally designed for measuring the DC resistance of the three-phase winding of the large-capacity transformer. It can measure the DC resistance of the three-phase winding at the same time. In case of the on-load voltage regulating transformer, it is not required to discharge but to directly adjust the tapping switch. The measurement time is one third of the traditional single-phase measurement, greatly shortening the working time and labor intensity. As the DC resistor tester is provided with large-screen LCD and the graphical interfaces, the operation is visual, clear and easy. Besides, it


is provided with panel type printer and large-capacity non-volatile memory, so the measurement results can be stored and printed out easily. With good stability in data testing, speediness and perfect repeatability, it is the best choice for the on-site measurement of DC resistance of transformer

2. Performance Index


Testing current	Single phase: 1A 5A 10A 20A 40A Three phase: 1A 5A 10A 20A
Measurement scope	Single phase: 1A 10 mΩ~20Ω 5A 1 mΩ~4Ω 10A 1 mΩ~2Ω 20A 1 mΩ~1Ω 40A 1 mΩ~0.5Ω Three-phase: 1A 10 mΩ~6Ω (each phase) 5A 1 mΩ~1Ω (each phase) 10A 1 mΩ~0.6Ω (each phase) 20A 1 mΩ~0.3Ω (each phase)
Measurement accuracy	±0.2% (Full span) ± 2 words
Maximum resolution	0.1μΩ
Data storage capacity	150 groups
Power supply	AC 220V±22V, 50Hz±2 Hz
Working environment	Ambient temperature: 0°~40° Relative humidity :≤80%


3. Panel Description

The panel of DC resistance tester is shown in the figure below:




- ① I_a I_b I_c : The dc current output. In case of single phase or two-phase measurement, I_a and I_b are current output.
- ② U_a U_b U_c U_o : The input of measuring voltage. In case of single-phase measurement, U_a and U_b are voltage input. In case of two-phase measurement, U_a and U_b are the voltage input of the first channel; U_c and U_o are the input of the second channel.
- ③ Panel printer: Prints the output measurement results.
- ④ LCD: displays the measurement results and operation prompting information, with the function definition of the five multi-function key-presses under the current state given in the key definition zone on the right, as shown in the figure below :

2 0 0 7 . 0 1 . 0 1		Set
Measurement mode: three phase Measuring current: 20 A		
Wiring Diagram		View
		Mode
		Current
		Measure
1 4 : 0 2 : 5 1		

- ⑤ : Contrast regulation of LCD
- ⑥ Power socket: the power input of the complete unit, with built-in fuse tube. The fuse tube is 10A/250V.
- ⑦ Earthing pole: The earthing pole on the enclosure of the complete unit. Make sure that it is reliably grounded during measurement.

4. Testing and Operating Method

- ① Connect with the power source and earth wire, switch on the power supply to enter into the initial interface, as shown in the figure below:

2 0 0 7 . 0 1 . 0 1		Set
Measurement method: Three phase Testing current: 20 A		View
Wiring Diagram		Mode
		Current
		Measure
		1 4 : 0 2 : 5 1

“Set” key-press: Set the current date and time.

“View” key-press: View the data stored, including measurement results, testing date, tapping number and etc.


“Mode” key-press: Sets the measurement mode, including “Single Phase”, “Two-phase” and “Three-phase”, besides, corresponding schematic wiring diagram will be displayed in the zone of “Schematic Wiring Diagram” as the reference for actual wiring.

“Current” key-press: Sets the size of testing current. In case of the single-phase or two- phase measurement, the current 1A, 5A, 10A and 20A can be selected. You may select suitable measuring current by referring to the related parameters listed in the technical indicators as the reference.

“Measure” key-press: After the testing wire is connected and the measuring current is selected, press “Measure” key-press to start the test.

② Single-phase measurement:

The wiring method is shown in the figure below (Taking the measurement as of R_{AB} an example):



After the winding under test is wired and the suitable measuring current is selected, press the “Measure” key-press to allow the tester to enter into its measuring state and to start to supply power to the winding, and then it enters into the interface as follows:

2007.01.01		Tap
R	<input type="text"/> 0.0 A	Store
The battery is charging, please wait a moment ! Current tap: 01		Print
		Re-test
		Exit
14:02:51		

At this time, the current of the winding starts to increase. If the charging progress strip and the current display value stand still for a long time, it indicates that the value of the resistance value to be measured is probably beyond the measuring scope of the current, so it is not able to reach its set value. At this time, press “Exit” key-press to return and re-select the current and retry. When the set value is reached, it becomes constant. Then, enter into the next interface.

2007.01.01		Tap
R	351.2 mΩ	Store
Current tap: 01		Print
		Re-test
		Exit
14:02:51		

Now, the dc resistance tester starts to display the resistance value of the winding under test and such value gradually becomes stable. At this time, press the Tap button to adjust and set the current tap value or winding name so as to mark the measurement result. After the Tap button is pressed down, the multi-functional key on the right becomes “▲” “▼” “◀▶” “OK” and “Cancel”, and the tap setting dialogue box is ejected. After setting, press “OK” button to save it and press “Cancel” button to modify it. Then, press “Store” and “Print” button to save or print the measurement result. In case of any doubt about the data, press “Retest” button to carry out the measurement and calculation again.


When measuring the on-load voltage changing transformer, after the testing data of one tapping position becomes stable, the on-load tapping switch may be switched to the next tapping position, without discharging to conduct the measurement over again. At this time, the resistance value of the winding will change gradually until it becomes stable. You may also press “Re-test” button to quickly refresh the data. Repeat the above-mentioned procedure until all the tapping tests are completed.

③ Three-phase measurement:

The three-phase measurement applies to the windings of YN star connection with neutral lead. For the windings of yn connection, since difference exists between the three-phase and single-phase measurement results due to the effect of copper bus connected, single-phase

measurement is recommended.

The three-phase wiring is shown in the figure below:



After the winding under test is wired and the suitable measuring current is selected, press the “Measure” key-press to allow the tester to enter into its measuring state and to start to supply power to the winding, and then it enters into the interface as follows:

2007.01.01			Tap
A	<input type="text"/>	0.0 A	Store
B	<input type="text"/>	0.0 A	
C	<input type="text"/>	0.0 A	
The battery is charging, please wait a moment ! Current tap: 01			Print
			Re-test
			Exit
14:02:51			

At this time, the current of the winding starts to increase. If the charging progress strip and the current display value stand still for a long time, it indicates that the value of the resistance value to be measured is probably beyond the measuring scope of the current, so it is not able to reach its set value. At this time, press “Exit” key-press to return and re-select the current and retry. When the set value is reached, it becomes constant. Then, enter into the next interface.

2 0 0 7 . 0 1 . 0 1		Tap
A	3 5 1 . 2 mΩ	
B	3 5 0 . 6 mΩ	Store
C	3 5 1 . 6 mΩ	
Imbalance rate: 0 0 . 2 8 % Current tap : 0 1		Print
		Re-test
		Exit
1 4 : 0 2 : 5 1		

Now, the dc resistance tester starts to display the resistance value of each phase. With the resistance value of each phase becoming stable, the imbalance rate will gradually decrease. Under such state, the “Tap” button may be pressed to adjust and set the current tap value or winding name so as to mark the measurement result. After the “Tap” button is pressed down, the multi-functional key on the right becomes “▲” “▼” “◀▶” “OK” and “Cancel”, and the tap setting dialogue box is ejected. After setting, press the “OK” button to save it and press the “Cancel” button to modify it. Then, press “Store” and “Print” button to save or print the measurement results. In case of any doubt about the data, press “Retest” button to carry out the measurement and calculation again. The maximum display scope of the imbalance rate is 50%. If such scope is exceeded, only “50%” will be display.

When measuring the on-load voltage changing transformer, after the testing data of one tapping position becomes stable, the on-load tapping switch may be switched to the next tapping position, without discharging to conduct the measurement over again. At this time, the resistance value and imbalance rate of each phase will change gradually until they become stable. You may also press “Re-test” button to quickly refresh the data. Repeat the above-mentioned procedure until all the tapping tests are completed.

Upon the completion of the measurement, press the “Exit” key to end the measurement. At this time, the DC resistance tester starts to discharge and the display gives corresponding discharge indication and the buzzer rings. After the discharge is completed and the tester

returns to the initial interface, the measurement wiring may be removed.

5. Precautions

- ① When measuring the no-load voltage changing transformer, be sure to exit from the discharge before switching the tapping switch. Do not switch the tapping switch before the discharge is completed according to the discharge indication.
- ② Do not remove the wiring during the measurement.
- ③ If the charging progress strip and the current display value stand still for a long time, it indicates that the value of the resistance value to be measured is probably beyond the measuring scope of the current, so it is not able to reach its set value. At this time, press the “Exit” button to return and reselect the current to retry.
- ④ When replacing the fuse tube and the fittings, please use the same model as this instrument.

6. Troubleshooting

Fault phenomenon	Cause analysis	Solution	Remarks
There is no display after switching on.	1) The power supply is not switched on.	Switch on the power supply	Replace with the fuse tube of the same model. Do not substitute it with the fuse tubes of other models.
	2) The 10A fuse tube of the instrument is not properly fitted or the circuit is open.	Fit or replace the fuse tube	
There is no current output	1) The equipment to be tested is open-circuited	Check the equipment and eliminate the faults.	
	2) The test circuit is open-circuited.	Check the test circuit and eliminate the open-circuit fault.	

7. Transportation and Storage

■ Transportation

When transporting the equipment, it is suggested using the instrument packing wood boxes and damping materials of our company to avoid any unnecessary damage and loss during the transportation.

Do not stack the equipment if it is not transported in a wood box. If the instrument packing box

of our company is used, the maximum permissible stacking layers are two layers.

The equipment shall be transported with the instrument panel facing upward.

■ Storage

The equipment shall be stored in the dry, dust-free and well-ventilated room without corrosive gas. Do not stack the equipment if it is not packed in the wood box.

The equipment shall be stored with its panel facing upward. Besides, damproof materials shall be provided at its bottom to protect it from dampness.

8. Unpacking and Inspection

■ Precautions for unpacking

Before unpacking, make sure that the arrow on the package of the equipment is upward. When unpacking, do not knock it by force, otherwise the equipment will be damaged. Unpack and take out the equipment. To protection the environment, keep the equipment package and damping materials so that you can use them for future transportation and storage.

■ Inspection content

Take out the equipment and check and count the equipment and fittings against the packing list. In case of any shortage, please make contact with our company. We will give serve you as soon as possible.

9. Others

The warranty period for the whole set of this product is one year and “Three-guarantees” (repair, return and exchange guarantees) is implemented. Maintenance service can be provided throughout its service life. For any quality problem of the equipment within the warranty period, free maintenance will be provided. For the damages due to the improper operation or carelessness of the user, services will be provided at favorable prices.

We are looking forward to your precious suggestions about our product. If the address and contact information of your company are changed, please keep us informed so that we can serve you in good time.